

FIBEX

15 Alarm Vibrating Watch
Item: FIBEX15VXXX

Thank you for purchasing the FIBEX Vibrating watch

Your watch has the following functions:

- Up to 15 daily auto-repeating alarms
- Smart countdown timer
- Notification types: Vibrate & Flash or Vibrate Only
- Alarm Duration 30 seconds, 60 seconds (Alarm 1 Only)
- Illuminated Screen
- Rechargeable internal battery



Warranty

The inner components of this watch are warranted to be free from defects in materials and manufacturer's workmanship for one (1) year from the original date of purchase. This warranty does not cover the band, buckle, battery, case, buttons or the quartz crystal. Do not wear this watch in the shower or swimming pool, it is NOT WATERPROOF. This warranty expressly excludes incidental and consequential damage caused by use, misuse, neglect, accident, unauthorized modification, or any defects resulting from service by anyone other than the manufacturer. During the warranty period, and upon proof of purchase, this watch will be repaired or replaced (with the same or a similar model) at the manufacturer's discretion. The watch is only a supplement to any memory system that you currently use to remind yourself to take your medications or perform medical tasks. The user maintains full responsibility to administer medications or perform medical tasks at the appropriate times. We assume no responsibility for any incidental or consequential damages, including but not limited to damages or injuries resulting from malfunction of the product, mathematical inaccuracy, or loss of stored data.

Warnings

- Charge the battery if the buttons stop working, the alarm is faint or if the watch alarms/vibrates erratically.
- DO NOT IMMERSE IN WATER. Avoid exposing the watch to temperature extremes. Avoid dropping the watch. Avoid exposing the watch to gasoline, cleaning solvents, adhesive agents, paint, or aerosol sprays.
- In no event will we be liable for loss of data or damages arising from such loss. This watch will withstand splashes and rain but is not waterproof. DO NOT USE IN SHOWER, BATHTUB OR SWIMMING POOL.

Charging: Please charge fully before first use.

1. Gently pull to remove the watch face from the band to reveal the USB contacts.
2. Plug the watch into your power bank, laptop, or desktop computer.
 - A full charge takes about 1 hour. When charging, the watch will display a blinking blue light.
 - A full charge lasts 6-20 days, depending on usage and number of daily alarms.
 - Charge before the battery is completely depleted to save the current time and countdown timer settings. The daily alarms will be saved even if the battery dies.
 - To check if vibration is working, press any button when the watch is charging.

Setting The Time:

1. When the screen is black, press the top button once to display the time.
2. Hold down the top button until the hours flash. Press the top button to increase the hours, or the bottom button to decrease.
3. Hold down the top button until the minutes flash. Press the top button to increase the minutes, or the bottom button to decrease.
4. Hold down the top button until 12H or 24H show, press any button to select 12H or 24H.

Setting up to 15 alarms

1. Press the top button 3 times. ALM will display.
2. Press the top button again to cycle through all 15 alarms.
3. Hold down the top button until hours flash. Press the top button to increase the hours, or the bottom button to decrease. Hold down the top button until the minutes flash. Press the top button to increase the minutes, or the bottom button to decrease.

Turn Individual Alarms off or on

1. When the screen is off, press the top button repeatedly until you see the time of the alarm you want to turn on or off.
2. Press the top button until you see A#ON or A#OF. Example: A1OF: Alarm 1 is turned off. A1ON: Alarm 1 is turned on.
3. Continue to press the top button to cycle through all the alarms.
 - Repeat steps 1-2 to modify any alarm

Setting The Timer:

1. When the screen is off, press the bottom button repeatedly to display Cdn, 1, 5, 10, 15, 20, 30, 45, 60, 90, 120, 180.
2. When you reach your desired interval hold down the bottom button until "ON" appears.

Check The Timer:

1. Press the bottom button to check time remaining, press again to see the current time, and again to see the battery level.

Turn off The Timer:

1. When the screen is off, press the bottom number to display the time remaining
2. Hold the bottom button for 5 seconds until "OFF" appears
3. **Tip:** if you want to change the current time after setting the timer, first turn off the timer.

Basic Actions:

- To Check Time: Press top button once.
- To Check Battery Level: Press top button twice
- To Check Alarm Settings: press top button 3 times
- To Check Countdown Timer Settings: Press the bottom button once
- **Alarm Turn Off Mode:** (This will temporarily deactivate all alarms set). Press any button to turn on the screen, then quickly hold both buttons together for 6 seconds. When complete, "SIL" will show. Hold both buttons for 6 seconds to reactivate all alarms. "VIB" will show.

Notes:

- Alarm 1 has a longer alarm time – 60 seconds – to be used as a wake-up alarm.
- All other alarms are 30 seconds long.
- The vibration can be stopped immediately by pressing any button.
- Alarms automatically repeat on schedule daily
- Alarms vibrate and flash
- The countdown timer vibrates only (totally discreet)